

INSTRUMENTS & CONTROLS

REAR WINDOW WASHER SWITCH. Keep switch depressed for prolonged washer operation.

REAR FOG LAMP SWITCH. Depress to operate. The rear fog lamp should only be used in poor visibility.

RADIO (+)

HEATING/VENTILATION
Upper Lever — Temperature control. Move to right for cold air, or to left for warm air. Lever may be set to any desired intermediate position.
Lower lever — Air distribution. Move to right ▲ to direct air to screen, to centre ▼ to direct air to vehicle interior. Position lever between ▲ and ▼ to direct air to screen and interior. Heater is switched off when lever is moved fully to left.

Boost fan switch —
Centre position: boost fan off
Lower position: slow boost
Upper position: high boost

INSTRUMENT ILLUMINATION CONTROL. Rotate to adjust brightness of the instrument panel illumination.

OIL PRESSURE GAUGE. If needle enters orange sector during normal running, stop car, switch off engine, and check for fault.

OIL PRESSURE WARNING LIGHT. If this light illuminates when driving, stop car, switch off engine and check for fault. (+)

AMMETER. This gauge should normally register a reading slightly to the 'plus' side of centre. Should the needle deviate consistently from this reading, the electrical system should be checked by a FORD Dealer.

HANDBRAKE/BRAKE FLUID LEVEL WARNING LIGHT. Light will go out when handbrake is released. Light also functions as a brake fluid level warning light. If light illuminates when driving, stop the car immediately it is safe to do so and have braking system checked at once.

TACHOMETER. Max continuous engine speed (rev/min).
4-cyl. in-line engine: 5,800
V6 engine: 5,700
Max intermittent engine speed (rev/min):
4-cyl. in-line engine: 6,100
V6 engine: 6,000

FUEL GAUGE. When needle enters orange sector there is a minimum fuel reserve of 10 litres (2 gallons) left in tank.

TEMPERATURE GAUGE. If the needle enters orange sector, stop car, switch off engine and check for fault.

MAIN BEAM WARNING LIGHT. The blue warning light will illuminate whenever the headlamps are on main beam, or when the headlamp flasher is operated.


DIRECTION INDICATOR WARNING LIGHT. The warning light flashing frequency will increase if an indicator bulb fails.

SPEEDOMETER

AEROFLOW VENT. This supplies unheated fresh air from outside the car. Turn the knob in the centre of the vent to adjust the volume of air discharged. Swivel vent to required direction (e.g. to side windows).

Air flow is increased by switching on the boost fan. (Boost fan switch is on the left-hand side of the heating and ventilation control levers).

BONNET RELEASE LEVER. Pull lever to release the bonnet. After releasing bonnet, push the safety catch at the front upwards. The bonnet can now be raised and supported by its strut. Before closing bonnet make sure that the strut is firmly engaged in its clip. Firmly close the bonnet to ensure that the lock is engaged. For safe driving it is important that the bonnet is properly locked.



HAZARD FLASHER SWITCH (+)

STARTER SWITCH/STEERING LOCK
This has four positions:

- 0 Steering locked; push key and lock barrel into lock approximately 3 mm (1/8 in), before turning key from position 0 to position I.
- I Steering unlocked, radio operative. Electrical systems operative. If the vehicle is being towed, the key must be in this position.
- II Start engine (+)

IGNITION WARNING LIGHT
If this light illuminates when driving, stop car, switch off engine and check for fault. (+)

TRIPMETER RESET BUTTON. Depress to zero tripmeter.

HEATED REAR WINDOW SWITCH (+)

REAR WINDOW WIPER SWITCH

CIGARETTE LIGHTER. Depress knob. After a short time it will pop up in the socket ready for use.

CLOCK. To adjust, push in central button and rotate as required.

ASHTRAY. To remove, open half-way and pull gently out while rocking it from left to right. Ensure guide pins engage when refitting.
Rear ashtrays: Swivel to open. To remove, depress centre retaining clip.

CHOKE CONTROL (+)

LIGHTING SWITCH
1 — Side and tail lights on.
2 — Headlamps, side and tail lights on. The headlamps will be on main or dipped beam, depending on the position of the multi-function switch.


MULTI-FUNCTION SWITCH

- 1 — Headlamps flasher
- 2 — Main beam when headlamps on
- 3 — Right turn indicators
- 4 — Left turn indicators
- 5 — Horn



WASH/WIPE SWITCH

- 1 — Normal wiper speed.
- 2 — Fast wiper speed — for extreme conditions.
- 3 — Intermittent wipe function. Use in light rain or mist.
- 4 — Windscreen washers — keep button depressed for prolonged washer operation. At the same time the headlamp washers, if fitted, will operate providing the vehicle lighting is switched on.



INTERIOR & EXTERIOR EQUIPMENT

SLIDING ROOF

In addition to the normal sliding roof operation the rear edge of the roof panel may be tilted provided the panel is closed.

Opening/Closing sliding roof: Pull winder handle out of recess, pull small lever in recess down. Wind handle anti-clockwise

to open the roof, or clockwise to close it. Fold handle back into recess.

Tilting roof panel: Pull winder handle out of recess, push small lever in recess up. Wind handle clockwise to tilt the roof, or anti-clockwise to lower it. Fold handle back into recess.

INTERIOR LIGHT


The light has three switch positions:

- — light on
 - — light off
 - — light on when door is opened.
- On some models an additional interior light is located in the luggage space.


MANUAL TRANSMISSION

The illustrations show the position of the individual gears, dependent on type of engine fitted.

1.3 and 1.6 litre engines: Depress gear lever to engage reverse gear.



2.0 and 3.0 litre engines: Move gear lever against spring pressure to engage reverse gear.



AUTOMATIC TRANSMISSION SELECTOR

Selector positions:

- P — Park/starter operative
- R — Reverse
- N — Neutral/starter operative
- D — Drive (1st, 2nd and 3rd gear)
- 2 — Second gear

1 — First gear



— Depress button on 'T' handle between these positions.


Safety note:

On vehicles with automatic transmission apply handbrake and select P when:

- Parking vehicle;
- Making adjustments under bonnet;
- Leaving the vehicle with engine running.

Do not rev engine above 4,500 rev/min with the vehicle stationary. (+)

SEAT BELTS (+)




DIPPING MIRROR
Pull lever to dip mirror.

GLOVE COMPARTMENT

The glove compartment is lockable. To open, turn knob on lid clockwise.

EXTERIOR MIRROR REMOTE CONTROL

Lever can be swivelled in any direction for adjusting mirror to required position.



SEAT BACK RECLINING LEVER
Lift lever to adjust angle of seat back. Note: On some models, adjustment is made by turning a handwheel.

SEAT BACK RELEASE LEVER
To gain access to rear seats raise lever and tip seat-back forward.

SEAT SLIDE LEVER

Pull the lever outward, slide the seat to the required position, then release the lever.

TAILGATE LOCK

Insert key and turn anti-clockwise to unlock. Push in lock button to open tailgate.

REAR SEAT BACKS

To fold a rear seat back flat, release appropriate catch ① in direction of arrow and fold seat back ② forward until it locks with a click. Return seat back to upright position by pulling lever ③ forward and raising the seat back fully.



PARCEL TRAY

To remove, unhook both straps ①, then lift guide pins ② out of parcel tray supports.

